



## Frequently Asked Questions



### What does the Scrambler do?

The Scrambler is an overdrive pedal that delivers classic Ampeg grit, grind, and sag.

### How is the Scrambler powered?

The Scrambler is powered by either a standard 9V battery or the optional AC adapter.

### How do I change the battery in my pedal?

Unscrew the four screws on the bottom of the pedal to access the battery.

### My bass sounds weak through the pedal. What's up?

This is often due to a dying battery. Try changing your battery or plugging in the optional AC adapter. You may also want to check your cables and instrument.

### My pedal works in bypass, but there is no signal when it's turned on.

Check to ensure that the optional AC adapter or battery has the correct voltage and/or polarity. Ensure that your cables are plugged into the correct input/output jacks.

### Can I use my USA-bought Scrambler overseas?

Yes. You will need to either use batteries, or purchase the proper AC adapter for the country you will be using it in.

### What is the output of the Scrambler's optional power supply?

9V DC, plug is center Negative.



## Frequently Asked Questions

**Can I plug headphones into my Scrambler?**

This is not recommended. Most headphones have a very high impedance. You will in all likelihood not get the results you are looking for.

**Can I use my (Brand X) AC adapter with my Scrambler?**

Yes, as long as the output is 9 Volts DC and the plug is center Negative. The current should be 100ma or higher.

**Can I use the Scrambler in my Effects Loop?**

Typically the Scrambler is best used between your bass and the input of your amplifier but it can also be used in an effects loop.

**Can I use the Scrambler to drive a power amp?**

Yes, absolutely. The Scrambler outputs a line-level signal comparable to most other preamps.

**Can I connect the Scrambler directly into a mixing console?**

Yes, you sure can!

**Does the Scrambler have "True Bypass" switching?**

Yes.

**Can I plug the Scrambler in between my amp head and my cabinet?**

No. The Scrambler should only be connected to the input or effects loop of your amplifier,

**How long will my battery last?**

The Scrambler has a minimal current draw, so a fresh battery should last around 8-10 hours.

**My active bass is overloading the input of the Scrambler.**

On the inside of your pedal is a jumper that you can move to pad your input down by 15db. Unscrew the four screws from the bottom of the pedal to access the jumper. Pins 1-2 are used for normal operation. Move the jumper to Pins 2-3 for 15db pad.