



Ampeg[®]

Frequently Asked Questions

MICRO CL

Question: Can I use a second speaker cabinet with my MicroCL head?

Answer: No. The head is designed with only one 8Ω speaker output.

Question: What is the difference between the two input jacks on the front of the head?

Answer: The input on the left is a direct input with no gain reduction built into the circuit. The input on the right is designed with a -15dB gain reduction circuit for active basses that provide too much input.

Question: How does the AUX input work?

Answer: The AUX input can provide playback from a consumer source such as an .mp3 player or cd player.

Question: Why will my speaker not work when I have headphones plugged into the jack in the front?

Answer: The headphone jack will break the signal if anything is plugged into it. You must remove the headphone jack to resume signal to your cabinet.

Question: Is the line out balanced or unbalanced?

Answer: The output MicroCL is unbalanced.